

INTERMAT 9943 PUSH TO OPEN T 42

HETTICH







Minimum de largeur utile : 85 mm pour une la distance
 Les valeurs de réglage s'appliquent à des portes sans épaisseur de 8

Distance Epaisseur de porte

| Distance | 85 | 100 | 117 | 135 | 150 | 165 | 180 | 200 | 220 | 240 | 255 |
|----------|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|
| 0 | 2,0 | 2,7 | 3,2 | 3,8 | 4,2 | 4,8 | 5,5 | 6,2 | 6,8 | 7,5 | 8,2 |
| 1 | 2,0 | 2,7 | 3,2 | 3,8 | 4,2 | 4,8 | 5,5 | 6,2 | 6,8 | 7,5 | 8,2 |
| 2 | 2,0 | 2,7 | 3,2 | 3,8 | 4,2 | 4,8 | 5,5 | 6,2 | 6,8 | 7,5 | 8,2 |
| 3 | 2,0 | 2,7 | 3,2 | 3,8 | 4,2 | 4,8 | 5,5 | 6,2 | 6,8 | 7,5 | 8,2 |
| 4 | 2,0 | 2,7 | 3,2 | 3,8 | 4,2 | 4,8 | 5,5 | 6,2 | 6,8 | 7,5 | 8,2 |
| 5 | 2,0 | 2,7 | 3,2 | 3,8 | 4,2 | 4,8 | 5,5 | 6,2 | 6,8 | 7,5 | 8,2 |

Tableau des dimensions de
Embossement de porte T
Distance T
et hauteur Distance H

| Distance | 0 | 1 |
|----------|-------|------|
| 100 | 100,0 | 9,0 |
| 117 | 117,0 | 17,0 |
| 135 | 135,0 | 35,0 |



<https://www.socomenal.com/intermat-9943-push-to-open-t-42-p28024>




Tel : 03 88 78 96 96

Fax : 02 43 30 26 16

www.socomenal.com

INTERMAT 9943 PUSH TO OPEN T 42

HETTICH



<https://www.socomenal.com/intermat-9943-push-to-open-t-42-p28024>




Tel : 03 88 78 96 96

Fax : 02 43 30 26 16

www.socomenal.com

INTERMAT 9943 PUSH TO OPEN T 42

HETTICH



<https://www.socomenal.com/intermat-9943-push-to-open-t-42-p28024>




Tel : 03 88 78 96 96

Fax : 02 43 30 26 16

www.socomenal.com

INTERMAT 9943 PUSH TO OPEN T 42

HETTICH



<https://www.socomenal.com/intermat-9943-push-to-open-t-42-p28024>



Tel : 03 88 78 96 96

Fax : 02 43 30 26 16

www.socomenal.com

INTERMAT 9943 PUSH TO OPEN T 42

HETTICH



<https://www.socomenal.com/intermat-9943-push-to-open-t-42-p28024>



Tel : 03 88 78 96 96

Fax : 02 43 30 26 16

www.socomenal.com